

WEATHER CONTROLLER MANUAL

LE CMP 6.0 ROAD WEATHER STATION

This document is owned by the company LED elektronika d.o.o.

It is strictly forbidden to reproduce or distribute to a third party any part of this document without the prior written permission of LED elektronika d.o.o., regardless of the means or method, whether electronic or mechanical; including photocopying.

Transfer of the contents of this document to a third party is not permitted without the prior written consent of LED elektronika d.o.o..

Please note that the document is subject to change without prior notice.

1. ESTABLISHING COMMUNICATION WITH THE METEOROLOGICAL STATION

Communication with the station can take place in several ways:

- via the serial RS485 communication input for service communication at the station itself (labels: "OUT(RS485)"),
- via Ethernet and IP technology: local and remote (labels: "ETH")
- by connecting to the local route device (road traffic station),
- remotely from the competent traffic management and control center via the basic communication network (Ethernet / optics SM, MM)

1.1. Local connection

Local connection can be performed using a terminal program (e.g. Terminate, Modscan, Hercules, etc.).

The "Termite" terminal was used as an example for connection.

When starting the terminal, delete the record history by clicking the "Clear" command.



For serial communication, it is necessary to adjust the settings as follows (click on the "Settings" command to open an additional "Serial port settings" window):

- PORT – set the COM port through which communication takes place
- BAUD RATE: 19200
- DATA BITS: 8
- STOP BITS: 1
- PARITY: none
- FLOW CONTROL: none
- FORWARD: none
- TRANSMITTED TEXT: select "Append CR" and check "Local echo"
- RECEIVED TEXT:
 - o Polling-100ms
 - o Max.lines - leave blank

- Font-default
- Uncheck "Word wrap"
- OPTIONS: check "Quit on Escape", "Autocomplete edit line", "Keep history", uncheck other parameters
- PLUG-INS: uncheck all parameters

After all the necessary settings have been configured, click on the confirmation of the selection ("OK") and if the connection is not established automatically, click on the command "click to connect".

Example: Retrieving data via serial communication



Connecting to the station via an IP client is done via any test computer. The test computer must be in the same subnet as the weather station (e.g. the predefined IP address may be 192.168.0.101/24, in which case the test computer should be in the same subnet).

Communication ends when the client closes the TCP/IP connection.


Additionally, as a possibility to check the operation and availability of measured data from the station, it is possible to check it via a web browser using the "VTO_LED CMP" web interface (it is not possible to read or download data from the meteorological station via the web interface).

By successfully connecting to the weather station controller, the commands shown and listed in the next chapter (Chapter: "2. Commands for local/remote data reading") can be entered and sent for the purpose of retrieving the necessary data from the weather station.

The format of received meteorological data as examples of responses from a meteorological station can be seen in Chapter 2, and the obtained measured quantities, units and ranges are described in Chapter 3 ("Tables of meteorological measured values").

The weather station can transfer all or part of the data from Table 1, depending on the number of sensors connected to it.

Example: Retrieving data via Ethernet and IP technology using the "Hercules SETUP 3.2.8" tool




1.2. Remote connection

Remote connection to the weather station is possible via TCP/IP connection. The protocol to the station is in ASCII format. Each command sent to the station must have a UNIX line termination method, i.e. it must end with CR (carriage return).

2. COMMANDS FOR LOCAL/REMOTE DATA READING

2.1. COMMAND: mes?<CR>

Retrieve measurement data in a structured printout and read sensor status.



2.2. COMMAND: mes14?<CR>

Retrieve measurement data and print it in the format recommended for retrieving measurement data from the central system.

With the command "mes14" the station returns the read measurements of each sensor and each measurement adjusted for retrieving measurement data from the central system. The obtained measurements are defined in the table at the end of the document called *"Table 1. - Measurement quantity, unit and range"*

Example:

```
months14?<CR>
```

```
month14?
2024-06-26 18:29,01,M14,Test_desc
01 23.7;02 53.1;03 13.6;12 995.0;05 //;06 //;07 //;80 //;
81 //;23 0.0;08 0.0;09 0.0;82 0.0;11 //;30 23.4;31 23.2;
46 23.2;35 23.2;36 10.0;40 10.0;42 0.0;43 23.2;86 0.8;85 23.2;
=
```

Remark:

Eg: "01 23.7;"

"01" - The first piece of information represents the "ID" of the sensor or measurement according to the names in the table below.

"Table 1. - Measurement quantity, unit and range"

"23.7" - The second data item represents the measurement data of the individual measurement data item under the "ID" of the first data item. The measurement data can be found in the table below:

"Table 1. - Measurement quantity, unit and range"

;" - symbol separating individual measurements

"//"- the symbol represents the non-measurable nature of the data. For additional interpretation of the symbol, it is necessary to read the measurement status under the corresponding ID using the "stat14" function.

2.3. COMMAND: rstat?<CR>

Retrieve the status of warning and alarm conditions.

Example:

```
rstat?<CR>
```

```
start?  
2024-06-26 18:29 01 Test_desc  
RAIN ICE FROST VISIBILITY  
0 0 0 0
```

=

Meanings of warnings and alarms:

RAIN :

0 = no warning

1 = rain warning (RAIN ALARM)

ICE:

0 = no warning

1 = ice warning (ICE Warning)

2 = ice danger (ICE alarm)

FROTS:

0 = no frost

1 = danger of frost (FROST alarm)

VISIBILITY:

0 = no danger

1 = visibility warning (VIS warning)

2 = visibility hazard (VIS alarm)

2.4. COMMAND: stat14?<CR>

Retrieve measurement data and print it in the format recommended for retrieving measurement data from the central system.

With the command "stat14" the station returns the status of each sensor and each measurement. The obtained statuses are defined in the table:

"Table 4. - Sensor Status"

Example of a weather station response:

```
stat14?<CR>
stat14?
2024-06-26 18:29,01,M14,Test_desc
01 00;02 00;03 00;12 00;05 ff;06 ff;07 ff;80 ff;
81 ff;23 00;08 00;09 00;82 00;11 ff;30 00;31 00;
46 00;35 55;36 00;40 55;42 00;43 55;86 00;85 55;
=
```

Remark:

Eg: "01 00;"

"01" - The first piece of information represents the "ID" of the sensor or measurement according to the names in the table below.

"Table 1. - Measurement quantity, unit and range"

"00" - The second data item represents the measurement status of the measurement data item under the "ID" of the first data item. The meaning of the data item can be read from

"Table 4. Sensor Status".

;" - symbol separating individual measurements

2.5. COMMAND: ports?<CR>

Access status status of digital inputs.

Example:

```
ports?<CR>
ports?
2024-06-26 18:29 01 Test_desc
IN1 IN2 IN3 IN4
1 1 1 1
=
```

Meaning of status and state of digital inputs:

1 = open, 0 = closed

IN1 - door open status

IN2 - mains power status (DC OK)
IN3 - UPS battery status
IN4 - surge arrester status

2.6. COMMAND: ports?<CR> timeset Dow Mnt Dy 00:00:00 CEST 2024<CR>

Command to set date and time.

Example:

```
timeset Fri Sep 6 13:17:10 CEST 2024<CR>
```

MET responds:

```
b'pet, 6.09.2024. 13:17:10 CEST\n'
```

Explanation:

Dow - day of the week (Mon, Tue, Wed, Thu, Fri, Sat and Sun)

Mnt - month of the year (Jan, Feb, Mar ...and so on)

Dy - day of the month (1, 2, 3...)

2.7. COMMAND: service?<CR>

Command to read the status of service measurements (sensor heaters, sensor voltage, etc.)

Example:

```
service?<CR>
```

```
2025-07-11 15:21 01 Test_desc
```

```
INTV INST STAT
```

```
SP 1 02M //ffff 0xff
```

```
RP 1 02M //ffff 0xff
```

```
SD 1 02M //ffff 0xff
```

```
TO 1 C 02M //ffff 0xff
```

```
HW 1 C 02M 0.0 0x24
```

```
HP 1 C 02M 26.8 0x00
```

```
VT 1 V 02M //ffff 0xff
```

```
HW 2 C 02M 0.0 0x2b
```

HP 2 C 02M 24.5 0x00

VT 2 V 02M 23.4 0x00

=

2.8. COMMAND: reboot?<CR> >

Command to reset the weather controller.

3. METEOROLOGICAL VALUE TABLES

Table 1. – Measurement quantity, unit and range:

Naziv mjerne veličine	sid	id	Jedinica	Raspon	Status senzora (STAT)
AIR TEMP	T	1	°C	-50.00 ... 60.00	Tablica 4
REL HUM	RH	2	%	0.00 ... 100.00	Tablica 4
DEW POINT	TD	3	°C	-50.00 ... 60.00	Tablica 4
REL AIR PRESS	CH	12	hPa	300.0 ... 1200.0	Tablica 4
W SPEED	WS	5	m/s	0.00 ...90.00	Tablica 4
W DIREC	WD	6	deg	0.00 ... 359.00	Tablica 4
AWG W SPEED	WA	7	m/s	0.00 ...90.00	Tablica 4
WIND GUST SPEED	WG	80	m/s	0.00 ...90.00	Tablica 4
MAX W SPEED	WM	81	m/s	0.00 ...90.00	Tablica 4
PREC TYP	RS	23	status	Tablica 2	Tablica 4
PREC QUAN	PR	8	mm	0.00 ... 100000.0	Tablica 4
PREC INTENS	RI	9	mm/h	0.0 ... 200.0	Tablica 4
PERC DIFF QUANT	PD	82	mm	0.00 ... 100000.0	Tablica 4
VIS	VI	11	m	10.0 ... 20000.00	Tablica 4
SURF TEMP	TS	30	°C	-40.00 ... 80.00	Tablica 4
GROUND TEMP 10cm	TG	31	°C	-40.00 ... 80.00	Tablica 4
GROUND TEMP 30cm	TG	46	°C	-40.00 ... 80.00	Tablica 4
FREZ TEMP *	TR	35	°C	-40.00 ... 0.00	Tablica 4
SURF STAT	ST	36	status	Tablica 3	Tablica 4
SALT QTY *	GE	40	g/m2	0.00 ... 100.00	Tablica 4
LAYER TICKNESS **	WT	42	µm	0.00 ... 4000.00	Tablica 4
SALT CONC *	CV	43	%	0.00 ... 100.00	Tablica 4
FRICTION	FR	86		0 ... 1	Tablica 4
ICE COVERAGE	CI	85	%	0.00 ... 100.00	Tablica 4

*Napomena: podaci se mjere samo u slučaju kada temperatura površine kolnika padne ispod 4°C

**Napomena: stanje površine kolnika ovisi o debljini vodenog sloja (<30um-suho, 30umvlažno<200um u >200um-mokro)

Table 2. – precipitation type status:

Status	Precipitation type
0	No precipitation

60	Rain
70	Snow
40	Unknown
67	Freezing rain
69	Blizzard
90	Fight

Table 3. – Roadway status:

Status	Road condition
10	dry
15	humid
20	wet
25	Wet salted
30	Wet salted
35	ice
40	snow
45	frost

**Note: the condition of the road surface depends on the thickness of the water layer (<30um-dry, 30um<wet<200um and >200um-wet)

Table 4. – Sensor status:

Status	Sensor status
0x00	OK
0x10	Unknown query
0x11	Invalid parameter
0x24	Invalid channel
0x28	Device is not ready.
0x50	Measured variable outside set range
0x51	
0x52	Measured data outside set range
0x53	
0x54	Measurement error
0x55	Measurements are not ready.
0xff	Data read failed

4. SETTING THE BASIC PARAMETERS OF THE METEO CONTROLLER

In the Command Prompt program, it is possible to change the IP address of the weather controller, set the weather station name, reset the controller, check the list of current directories, find out the permission levels, stop and start services, etc.

Each controller has a default IP address, user and password:

IP: 192.168.0.100

Username: user1

Password: LY234pVt1

To change the IP address, it is necessary to connect to the controller in the Command Prompt using the following command:

```
ssh user1@192.168.0.100
```

The program will then ask for a password (the entry is hidden and after entering it you need to click enter)

Then you need to open the configuration file using the following command:

```
sudo nano /etc/NetworkManager/system-connections/Wired Connection 1.nmconnection
```

After running the file in the field *ipv4* set *address1* (IP address, subnet mask and gateway) and *dns*, and add the line *ignore-auto-dns=true*

After entering data, save the changes with *ctrl+X* (exit) and then *ctrl+D* (save).

```

GNU nano 7.2 /etc/NetworkManager/system-connections/Zično_povezivanje_1.nmconnection *
[connection]
id=Zično_povezivanje_1
uuid=b13d16a6-584b-3670-9435-a8ec70428710
type=ethernet
autoconnect-priority=-999
interface-name=eth0
timestamp=1720328510

[ethernet]

[ipv4]
address=10.0.15.236/24,10.0.15.254
dns=8.8.8.8;10.0.15.70;10.0.15.40
ignore-auto-dns=true
method=manual

[ipv6]
addr-gen-mode=stable-privacy
method=auto

[proxy]

Pomoć  Spremi  Traži  Izreži  Izvrši  Pozicija  Poništi  Označi
Izlaz  Učitaj dat  Zamijeni  Zalijepi  Poravnaj  U redak  Ponovi  Kopiraj

```

Changing the name of a weather station can be done using the following command:

```
sudo nano /etc/meteo_py/config.yaml
```

The first line contains name where you enter the desired name of the weather station.

After entering data, it is necessary to save the changes with ctrl+X (exit) and then ctrl+D (save).

Changes on the meteo controller will be visible only after the controller is reset. A controller reset can be initiated using the following command:

```
sudo reboot
```

```

GNU nano 7.2 config.yaml *
Name: M06_ME170
mid: 1
tcpport: 4001
masterck: 5 #broj zadnjih backupova baze koji se drži
backupsecd: 1 # za bazu, u tjednima, default 1 tjedan
masterport: /dev/ttyUSB0 #bilo 0

#1x WS100 1x WS400 1x VENTUS-X 1x VS20h 1x IRS31pro
#0x7002 ws400, 0x7001 ws100, 0x9001 irs31, 0x8001 ventus,0x3001 vs20

hwcfg:
- saddr: 0x7001
  sench: [620, 700, 825, 112, 113, 10000] #mahnuo 820, nema ga u sencfg. moza dati 605 float32 Precipitac
  port: /dev/ttyUSB1 #prebacio sa 1
  baud: 19200
  data: 8
  parity: N
  stop: 1
  protocol: LUFFT
- saddr: 0x7002
  sench: [100, 110, 200, 305, 625, 112, 113, 10000]
  port: /dev/ttyUSB1
  baud: 19200
  data: 8
  parity: N

```

To check the level of rights, the command is used:

`ls -al`

To check the current directory, use the command:

`pwd`

The list of current directories can be opened using the command:

`yes`

```

user@bropsherry:~$ ls -al
lsblkupno 220
drwxr-xr-x 30 user1 user1 4096 strp 10 09:48 .
drwxr-xr-x 3 root root 4096 pro 5 2021 ..
-rw-r--r-- 1 user1 user1 33078 strp 10 09:48 .bash_history
-rw-r--r-- 1 user1 user1 220 pro 5 2021 .bash_logout
-rw-r--r-- 1 user1 user1 2822 pro 5 2021 .bashrc
drwxr-xr-x 2 user1 user1 4096 pro 5 2021 .bookshelf
-rw-r--r-- 1 user1 user1 3 velj 10 2024 .brc.conf
drwxr-xr-x 16 user1 user1 4096 strp 0 09:24 .csaba
drwxr-xr-x 17 user1 user1 4096 kol 10 2024 .config
drwxr-xr-x 2 user1 user1 4096 velj 16 2024 .cups
drwxr-xr-x 3 user1 user1 4096 velj 16 2024 .dbus
drwxr-xr-x 2 user1 user1 4096 kol 15 2024 .dotnet
-rw-r--r-- 1 user1 user1 30 velj 13 2024 .drcr
drwxr-xr-x 2 user1 user1 4096 pro 5 2024 .Documents
drwxr-xr-x 3 user1 user1 4096 lip 5 13:46 .dotnet
drwxr-xr-x 2 user1 user1 4096 pro 5 2021 .Gizba
-rw-r--r-- 1 user1 user1 256 velj 10 2024 .habr.bin
-rw-r--r-- 1 root root 833 velj 10 2024 .habr.conf
drwxr-xr-x 2 user1 user1 4096 pro 5 2021 .Javno
-rw-r--r-- 1 user1 user1 20 svl 10 08:58 .lessht
drwxr-xr-x 4 user1 user1 4096 pro 5 2021 .local
drwxr-xr-x 2 user1 user1 4096 kol 10 2024 .METEO_GUI_logs
drwxr-xr-x 2 user1 user1 4096 kol 10 2024 .METEO_infrastruktura
drwxr-xr-x 4 user1 user1 4096 pro 5 2021 .mozilla
drwxr-xr-x 3 user1 user1 4096 velj 10 2024 .ip_backup
drwxr-xr-x 2 user1 user1 4096 pro 5 2021 .Preudici
drwxr-xr-x 2 user1 user1 4096 pro 5 2021 .Preuzimanja
-rw-r--r-- 1 user1 user1 807 pro 5 2021 .profile
drwxr-xr-x 5 user1 user1 4096 kol 17 2024 .pyinst
-rw-r--r-- 1 user1 user1 139 kol 10 2024 .python_history
-rw-r--r-- 1 user1 user1 256 velj 10 2024 .read.bin
drwxr-xr-x 2 user1 user1 4096 velj 10 2024 .slike
drwxr-xr-x 2 user1 user1 4096 pro 5 2021 .Snimke
-rw-r--r-- 1 user1 user1 0 pro 5 2021 .sudo_as_admin_successful
drwxr-xr-x 3 user1 user1 4096 velj 16 2024 .vnc
drwxr-xr-x 5 user1 user1 4096 lip 5 13:38 .vscode-server
-rw-r--r-- 1 user1 user1 183 lip 5 13:36 .wget-hsts
-rw-r--r-- 1 user1 user1 161 strp 0 09:39 .Xauthority
-rw-r--r-- 1 user1 user1 19098 strp 0 09:39 .xsession-errors
-rw-r--r-- 1 user1 user1 19096 strp 0 09:35 .xsession-errors.old
user@bropsherry:~$ pwd
/home/user1
user@bropsherry:~$ ls
bookshelf Desktop Gizba habr.conf METEO_GUI_logs Preudici pyinst slike
brc.conf Dokumenti habr.bin Javno meteo_infrastruktura Preuzimanja read.bin Snimke
user@bropsherry:~$

```

5. CONNECTING TO THE METEO CONTROLLER AND ADJUSTING THE SENSOR PARAMETERS IN THE CONFIGURATION FILE


To manage the sensor parameters, it is necessary to connect to the meteo controller using the winSCP program:

Host name: IP address of the controller



Username: user name



Password: enter password

After entering the required information, click Login.





After logging in, you need to select the folders in the order marked in the images below:





After opening the folder with the meteo files, it is necessary to open the config.yaml file in which

it is possible to adjust the parameters of the sensor, that is, to change the configuration of the meteo controller.



Within the header of the config.yaml file is general information related to the project:

```
name: Test_desc
middle: 1
tcpport: 4001
maxbck: 5 #number of last database backups kept
bckperiod: 1 # for the database, in weeks, default 1 week
master port: /dev/ttyUSB0
```

The data that you want to read from the sensor is entered inside hwcfg.

Example:

```
hwcfg:
  - address: 0x7001 // channel from which we read data from
    a particular sensor
  sench: [620, 700, 825, 112, 113, 10000]//addresses from which
    we read the desired
    measurements
  port: /dev/ttyUSB1
  baud rate: 19200
  date: 8
  parity: N
  stop: 1
  protocol: LUFFT// depending on the type of sensors used
```

Within sencfg, the parameters and display of data readings for each individual measurement are defined.

```
sencfg:
  - channel: 1
    id: 1
    name: T
    address: 0x7002
    sench: 100
    stat: 255
    unit: C
```

value: 65535
desc: air temp.
service: 0

On the weather controller, it is possible to simulate the values of measured data to confirm the correctness of data reading and alarm generation from it.

Data simulation is performed using the following parameter:

[simulated_data_and_stats: 1](#)

When the value of the parameter = 0, the data is read from the meteo controller. When the value of the parameter = 1, then the controller reads the data given to it in the configuration file.

Simulated values are entered for the values value and stat.

Loading simulated values is done with the command:

[reload_value_stat](#)

Disclaimer

LED elektronika doo emphasizes that the information contained in this document is the property of the company. Although LED elektronika doo strives to ensure high quality information, absolute accuracy cannot be guaranteed, therefore the company assumes no responsibility for possible injuries, losses or damages that may arise as a result of using or relying on the information in this document. Users should be aware that they are responsible for their own actions, decisions and the way of using the given instructions and information. Furthermore, LED elektronika doo clearly rejects any responsibility for the use of devices and software described in the document, stressing that their use must be in accordance with valid safety standards and instructions for use. In addition, the company reserves the right to change, supplement and delete the document without prior notice.

Disclaimer

LED elektronika doo emphasizes that the information contained in this document is the property of the company. Although LED elektronika doo strives to ensure high quality information, absolute accuracy cannot be guaranteed, therefore the company assumes no responsibility for possible injuries, losses or damages that may arise as a result of using or relying on the information in this document. Users should be aware that they are responsible for their own actions, decisions and the way of using the given instructions and information. Furthermore, LED elektronika doo clearly disclaims any responsibility for the application of the devices and software described in the document, emphasizing that their use must be in accordance with valid safety standards and instructions for use. In addition, the company reserves the right to change, supplement and delete the document without prior notice.